Application Techniques for Installation

APPLICAT	FLOATING			STAPLE/NAIL W/PGD			FULL GLUE DOWN						
S U B S T R A T E :					PLYWOOD						CONCRETE		
			BELOW GRADE		ABOVE GRADE		ON GRADE	ABOVE GRADE		ON GRADE	ABOVE GRADE	BELOW GRADE	ON GRADE
ENCORE	7″	~	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	~	\checkmark	\checkmark
	8″	~	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	~	\checkmark	\checkmark	\checkmark
PRESTIGE	7″				\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
	8″				\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark

Note: All CRAFT *Engineered Flooring* can be installed over Radiant Floor Heating systems. Please follow the *Creative At Home* and *NWFA* installation guidelines. Please submit the Homeowner Responsibility Form prior to installation.

Note: For ALL CRAFT Flooring products, we recommend gluing the end butt joints with Tongue & Groove adhesive applied to the bottom of the groove, for optimal performance.





CRAFT