

Recommended Adhesives for CRAFT Flooring

CRAFT floors are warranted as per the standard Creative At Home Warranty if the following recommended adhesives are properly followed:

Adhesives for Glue-down Installations of Engineered Flooring

- For wider than 7" engineered flooring, installation MUST be either a nail and glue combination, or full glue spread installation.
- With nail and glue installations, the glue should be applied in strips every 8 inches across the planks alternating with the nailing schedule, or as an "S" pattern down the length of the planks.
- Please carefully follow the instructions of the adhesive manufacturer.

Note – It is strongly recommended to do a thorough test of the adhesive before proceeding to install the whole floor.

Note – Follow the specification and installation guidelines as provided on our website: www.craftfloor.com/installation

R E C O M M E N D E D A D H E S I V E S								
<i>BRAND:</i>	<i>BOSTIK</i>							
<i>PRODUCT:</i>	BEST	BST	PROCURE	EFA+	VAPOUR LOCK	ULTRASET SINGLE STEP	GREEN FORCE	PRO-MSP
CRAFT APPROVED	✓	✓	✓	✓	✓	✓	✓	✓
WARMBOARD Radiant Floor Heat Approved	✓	✓	✓	✓	✓		✓	✓

R E C O M M E N D E D A D H E S I V E S									
<i>BRAND:</i>	<i>TITEBOND</i>						<i>SIKABOND</i>		
<i>PRODUCT:</i>	801	811	821	771	991	231	T21	T54	T55
CRAFT APPROVED	✓	✓	✓	✓	✓	✓	✓	✓	✓
WARMBOARD Radiant Floor Heat Approved		✓	✓	✓					✓

R E C O M M E N D E D A D H E S I V E S												
<i>BRAND:</i>	<i>MAPEI ULTRABOND ECO</i>				<i>BONA</i>		<i>STAUF</i>					
<i>PRODUCT:</i>	975	980	985	995MB	R850T	R851	SMP840	SMP960	CBR970	PIC850	PUK455	PUM950
CRAFT APPROVED	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
WARMBOARD Radiant Floor Heat Approved	✓	✓			✓	✓						✓